20V LITHIUM-ION BATTERY CHARGER FOR CP20V SERIES

MODEL NO: **CP20VMC**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instruction manual



Indoor use only

1. SAFETY

1.1. ELECTRICAL SAFETY

❑ **WARNING!** It is the user's responsibility to check the following:

✓ Check all electrical equipment and appliances to ensure that they are safe before using.

✓ Inspect power supply leads, plugs and all electrical connections for wear and damage.

✓ If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified person in order to avoid a hazard.

✓ Ensure that the insulation on all cables and on the appliance is safe before connecting it to the power supply.

× **DO NOT** use worn or damaged cables, plugs or connectors.

✓ Ensure that any faulty item is repaired or replaced immediately by a Sealey qualified technician.

✓ If the cable or plug is damaged during use, switch off the electricity supply and remove from use.

✓ Sealey recommend that an RCD (Residual Current Device) is used with all electrical products.

IMPORTANT: Ensure that the voltage rating on the appliance suits the mains power supply.

× **DO NOT** pull or carry the appliance by the power cable.

× **DO NOT** pull the plug from the socket by the cable.

✓ Ensure that repairs are carried out by a qualified electrician.

1.2. BATTERY CHARGER SAFETY INSTRUCTIONS

❑ **WARNING! DO NOT** use the charging base to charge any battery other than that required for the tool. Other types of batteries may explode!

✓ Inspect the plug, cable and the charging base for wear and damage to ensure items are safe before connecting to the mains power supply. If worn or damaged **DO NOT** use, immediately replace, or contact a qualified electrician.

✓ Check cables are always protected against short circuit and overload.

✓ Uncoil the power cable between the plug and the charging base before use.

× **DO NOT** pull or carry the charging base by the charger power lead, or pull the plug from the mains socket by the power lead.

× **DO NOT** use any other type of transformer with the charging base.

× **DO NOT** try to open or dis-assemble the plug or charging base.

× **DO NOT** use the plug to power any other electrical item.

✓ Disconnect the charging base from the mains power supply when not in use.

× **DO NOT** expose the charging base to damp or wet conditions (for indoor use only).

× **DO NOT** operate the charging base if it has been dropped, or has received a sharp knock, or is damaged. Contact an authorised service agent.

× **DO NOT** dismantle the charging base as this may cause damage or personal injury and will invalidate your warranty.

× **DO NOT** insert foreign objects or material into the slot reserved for the battery.

× **DO NOT** immediately charge a second battery. Consecutive charging will overheat the charging base. Allow the unit to cool for 15 minutes before charging the next battery.

✓ Ensure that the insulation on all cables and on the appliance is safe before connecting it to the power supply.

✓ Ensure that cables are always protected against short circuit and overload.

× **DO NOT** use worn or damaged cables, plugs or connectors. Immediately have any faulty item replaced by a qualified electrician.

1.3. BATTERY SAFETY PRECAUTIONS

❑ **WARNING!** Batteries contains Lithium-ion which is dangerous. Handle with care to avoid damage, fire, corrosion or personal injury.

✓ Charge battery prior to its first use. The battery will have been shipped in a low charge state. To reduce the risk of burns or fire:

× **DO NOT** attempt to open, disassemble, modify or service the battery pack.

× **DO NOT** crush, puncture, short external contacts or dispose of in fire or water.

× **DO NOT** expose to temperatures above 40°C (104°F).

✓ Use only the charging base to charge the CP20V series batteries.

❑ **WARNING!** Dispose of spent batteries correctly as they contain Lithium-ion. **DANGER! DO NOT** attempt to disassemble the battery. For safety and environmental reasons **DO NOT** discard in domestic waste or by burning. ONLY discard or recycle according to local authority regulations.

❑ **WARNING! DO NOT** allow a leaking battery to contact your person.

© Jack Sealey Limited

2. INTRODUCTION

Mains charger for Model No's CP20VBP2, CP20VBP, CP20VBP4, CP20VBP6 Power Tool Batteries. LED indicates status of battery from charging to full. Suitable for use with the CP20V Series.

3. SPECIFICATION

Model No.:	CP20VMC
Applications:	CP20VBP2, CP20VBP, CP20VBP4, CP20VBP6
Output:	20V DC
Supply:	230V AC~50Hz

4. OPERATION

NOTE-: When new, the batteries will have been shipped in a low charge state. Fully charge the batteries before using your tool.

4.1. To remove the battery from the equipment, depress the spring loaded button on the battery pack. Remove the battery pack by sliding out. **DO NOT** touch the metal battery terminals.

4.2. The battery is designed to fit into the charger one way only. Insert the battery fully and firmly to seat the battery into the charging base.

4.3. Take the base charger and plug it into the mains, switch on the power and the LED on the charger will illuminate.

4.4. When the battery is on charge the red LED on the charger will illuminate.

4.5. When the green LED on the Charger illuminates permanently the battery is fully charged.

4.6. Remove the battery from the charger. Switch off and remove the plug from the mains.

ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

REGISTER YOUR PURCHASE HERE

WEEE REGULATIONS

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Jack Sealey Ltd t/a Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk, IP32 7AR UK
Jack Sealey (EU) Ltd t/a Sealey Group, Farney Street, Carrickmacross, Co. Monaghan, A81 PK68 Ireland
Tel: 01284 757500 • **Email:** sales@sealey.co.uk • **Web:** www.sealey.co.uk

© Jack Sealey Limited