

# CONCRETE COLUMN SKIP



The Concrete Column Skip is ideal for pouring concrete into columns. It can also be used for walls, narrow formwork and pipe laying work.

With the delivery hose attached to the gate of the skip, the concrete flow can be easily directed.

The lay down design allows for easy filling and cleaning. The concrete column skip is a durable and robust piece of machinery, built to withstand wear and tear from use on construction sites.



**Safety tip:** The bale arm should be secured in a position that ensures it cannot swing down or drop on anyone when the skip is not in use.

## Key Benefits:

- 3-metre delivery hose included for precise pouring of concrete
- A wide range of sizes are available from 500 to 4000 litres
- Design allows for horizontal laying on the ground for easy filling

## Specification:

SWL (kg)	Capacity (ltr)	Hanging Height (mm)	Width (mm)	Weight (kg)
1200	500	2200	1050	290
2400	1000	2750	1200	380
3600	1500	2980	1500	570
4800	2000	3280	1500	650
7200	3000	3150	1800	1160
9600	4000	3500	1800	1390

*\*For additional sizes, please enquire with a member of the WOLFF Onsite team*