
SEALEY

THE TOOL COMPANY

PARTS INFORMATION

Heavy-Duty Floor Transmission Jacks

Model No. 1500E.V2



Item	Part No.	Description
1	1500E.V2-01	Wheel, Swivel Castor, Single Bolt (D:100 W:35 B:12 H:165)
2	SWM16.SB	Spring Washer M16 Black
3	SN16.S	Steel Nut M16 Zinc
4	1500E.V2-04	Frame
5	1500E.V2-05	Shaft
6	1500E.V2-06	Shaft
7	1500E.V2-07	Snap Ring
8	1500E.V2-08	Connecting Bar
9	1500E.V2-09	Snap Ring
10	1500E.V2-10	Bracket
11	1500E.V2-11	Shaft

Item	Part No.	Description
12	1500E.V2-12	Snap Ring
13	1500E.V2-13	Bracket
14	1500E.V2-14	Nut
15	1500E.V2-15	Bolt
16	1500E.V2-16	Pin
17	1500E.V2-17	Screw
18	1500E.V2-18	Knob, Metal, OD: 76mm L: 36mm, 14mm Female Fitting
19	1500E.V2-19	Lead Screw
20	1500E.V2-20	Nut With Thread For Allen Key
21	1500E.V2-21	Shaft
22	AK4567D.18	External Circlip 32.0mm ID.

© Jack Sealey Limited

Heavy-Duty Floor Transmission Jacks

THE TOOL COMPANY

Model No. 1500E.V2

Item	Part No.	Description
23	1500E.V2-23	Circular Nut
24	B/51102	Bearing Race 51102
25	1500E.V2-25	Bushing
26	1500E.V2-26	Shaft
27	1500E.V2-27	Shaft
28	GNM19S	Grease Nipple Str 6 x 1.00mm Single
29	1500E.V2-29	Arm
30	1500E.V2-30	Pin
31	1500E.V2-31	Shaft
32	1500E.V2-32	Rod Link
33	1500E.V2-33	Snap Ring
34	1500E.V2-34	Connecting Block
35	1500E.V2-35	Pin
1-1	1500EV2.1-1	Retaining Ring
1-2	1500EV2.1-2	Bushing
1-3	SBJ10W.11	O-Ring, (Ex: 49.92 In: 42.86 Cs: 3.53)
1-4	1500EV2.1-4	Piston Rod
1-5	1500EV2.1-5	Piston Ring
1-6	1500EV2.1-6	Sealing Washer
1-7	1000E.V2-35	O-Ring, (Ex: 44.95 In: 34.29 Cs: 5.33)
1-8	1500EV2.1-8	Steel Ring
1-9	1500EV2.1-9	Snap Ring
1-10	1500EV2.1-10	Hydraulic Unit
1-11	1500EV2.1-11	Oil filler Plug
1-12	1500EV2.1-12	Bushing
1-13	1500EV2.1-13	Bolt
1-14	1500EV2.1-14	Screw
1-15	1500EV2.1-15	Steel ball
1-16	1500EV2.1-16	O-Ring
1-17	SB-6.4	Steel Ball 6.4mm
1-18	SA316.10	O-Ring, (Ex: 12.83 In: 7.59 Cs: 2.62)
1-19	1500EV2.1-19	Oil Release Valve Rod
1-20	HPT1000.108	Spring Pin M4 X 20 Zinc
1-21	1500EV2.1-21	Knob, Metal, Red, OD: 60mm L: 34mm ID: 10mm, Female Fitting,
1-22	GSM66.S	Grub Screw m6x6 (Single)
1-23	1500EV2.1-23	Steel Ball
1-24	1500EV2.1-24	Ball Seat
1-25	1500EV2.1-25	Spring
1-26	1500EV2.1-26	Screw
1-27	1500EV2.1-27	Sealing Washer
1-28	1500EV2.1-28	Bolt
1-29	1500EV2.1-29	Spring
1-30	1500EV2.1-30	Steel Ball
1-31	1500EV2.1-31	Spring
1-32	1500EV2.1-32	Copper Washer
1-33	1500EV2.1-33	Bolt
1-34	1500EV2.1-34	Copper Washer Thin M18
1-35	1500EV2.1-35	E-Clip 7.8mm.
1-36	1500EV2.1-36	Pump Seat
1-37	1500EV2.1-37	Pin
1-38	1500EV2.1-38	Y-Seal
1-39	1500EV2.1-39	O-Ring, (Ex: 17.88 In: 13.20 Cs: 2.34)
1-40	1500EV2.1-40	Pump Plunger
1-41	1500EV2.1-41	Pump Cylinder
1-42	1500EV2.1-42	Dustproof Seal
1-43	1500EV2.1-43	Rod Joint
1-44	1500EV2.1-44	Pin
1-45	1500EV2.1-45	Jack Handle, Red (c/w Grip) Ø22 x 910mm (Flat Plate 96 x 36 x 13mm)
1-46	1500EV2.1-46	Handle Grip For Jack Handle
3-1	SCB825.SB	Socket Cap Bolt M8 x 25mm Black
3-2	SWM6.SB	Spring Washer M6 Black
3-3	FWM6.S	Flat Washer M6 Zinc
3-4	1500EV2.3-4	Chain
3-5	1500EV2.3-5	5/16 unc Half Nut
3-6	1500EV2.3-6	Screw
3-7	1500EV2.3-7	Saddle Angle

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. See www.sealey.co.uk for the latest information.
Important: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person.

Jack Sealey (EU) Ltd t/a Sealey Group Farney Street, Carrickmacross, Co. Monaghan, A81 PK68 Ireland
Jack Sealey Ltd t/a Sealey Group Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk, IP32 7AR UK
Tel: 01284 757500 ▪ **Email:** sales@sealey.co.uk ▪ **Web:** www.sealey.co.uk

© Jack Sealey Limited

Heavy-Duty Floor Transmission Jacks

Model No. 1500E.V2

Item	Part No.	Description
3-8	1500EV2.3-8	Saddle Base
3-9	1500EV2.3-9	Washer
3-10	SN12.SW	Wing Nut M12 Zinc
3-11	SN10.S	Steel Nut M10 Zinc
3-12	FWM10.S	Flat Washer M10 Zinc
3-13	1500EV2.3-13	Saddle Angle

Item	Part No.	Description
3-14	SN8.SW	Wing Nut M8 Zinc
3-15	1500EV2.3-15	Guide Screw
3-16	1500EV2.3-16	Hook Bolt
3-17	MSP612.S	Machine Screw Pan Head Phillips M6 X 12mm
3-18	1500EV2.3-18	Middle Plate For Saddle Base

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. See www.sealey.co.uk for the latest information.
Important: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person.

Jack Sealey (EU) Ltd t/a Sealey Group Farney Street, Carrickmacross, Co. Monaghan, A81 PK68 Ireland
Jack Sealey Ltd t/a Sealey Group Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk, IP32 7AR UK
Tel: 01284 757500 ▪ **Email:** sales@sealey.co.uk ▪ **Web:** www.sealey.co.uk

© Jack Sealey Limited