10.8V LITHIUM-ION FAST CHARGE BATTERY CHARGER FOR SV10.8 SERIES - EUROPEAN PLUG

MODEL NO: **CP108VMCEU**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instruction manual



Indoor use only

1. SAFETY

1.1. ELECTRICAL SAFETY

❑ **WARNING!** It is the user's responsibility to check the following:
Check all electrical equipment and appliances to ensure that they are safe before using. Inspect power supply leads, plugs and all electrical connections for wear and damage. Sealey recommend that an RCD (Residual Current Device) is used with all electrical products.
If the multi-tool is used in the course of business duties, it must be maintained in a safe condition and routinely PAT (Portable Appliance Test) tested.
Electrical safety information. It is important that the following information is read and understood.

1.1.1. Ensure that the insulation on all cables and on the appliance is safe before connecting it to the power supply.

1.1.2. Regularly inspect power supply cables and plugs for wear or damage and check all connections to ensure that they are secure.
Important: Ensure that the voltage rating on the appliance suits the power supply to be used and that the plug is fitted with the correct fuse - see fuse rating in these instructions.

× **DO NOT** pull or carry the appliance by the power cable.

× **DO NOT** pull the plug from the socket by the cable. Remove the plug from the socket by maintaining a firm grip on the plug.

× **DO NOT** use worn or damaged cables, plugs or connectors. Ensure that any faulty item is repaired or replaced immediately by a qualified electrician.

1.1.3. This product is fitted with a Schuko plug.
If the cable or plug is damaged during use, switch off the electricity supply and remove from use.
Replace a damaged plug with an appropriate plug. If in doubt contact a qualified electrician.
Class II products are wired with live (brown) and neutral (blue) only are marked with the Class II symbol; 
A) Connect the BROWN live wire to the live terminal 'L'.
B) Connect the BLUE neutral wire to the neutral terminal 'N'.
C) After wiring, check that there are no bare wires and ensure that all wires have been correctly connected.
Ensure that the cable outer sheath extends inside the cable restraint and that the restraint is tight.

× **DO NOT** connect either wire to the earth terminal.
Sealey recommend that repairs are carried out by a qualified electrician.

× **DO NOT** use worn or damaged leads, plugs or connections. Immediately replace or have repaired by a qualified electrician.

1.2. BATTERY CHARGER SAFETY INSTRUCTIONS

❑ **WARNING! DO NOT** use the charging base to charge any battery other than that required for the tool.
Other types of batteries may explode!

✓ Inspect the plug, cable and the charging base for wear and damage to ensure items are safe before connecting to the mains power supply. If worn or damaged **DO NOT** use, immediately replace, or contact a qualified electrician.

✓ Check cables are always protected against short circuit and overload.

✓ Uncoil the power cable between the plug and the charging base before use.

× **DO NOT** pull or carry the charging base by the charger power lead, or pull the plug from the mains socket by the power lead.

× **DO NOT** use any other type of transformer with the charging base.

× **DO NOT** try to open or dis-assemble the plug or charging base.

× **DO NOT** use the plug to power any other electrical item.

✓ Disconnect the charging base from the mains power supply when not in use.

× **DO NOT** expose the charging base to damp or wet conditions (for indoor use only).

× **DO NOT** operate the charging base if it has been dropped, or has received a sharp knock, or is damaged. Contact an authorised service agent.

× **DO NOT** dismantle the charging base as this may cause damage or personal injury and will invalidate your warranty.

× **DO NOT** insert foreign objects or material into the slot reserved for the battery.

× **DO NOT** immediately charge a second battery. Consecutive charging will overheat the charging base. Allow the unit to cool for 15 minutes before charging the next battery.

✓ Ensure that the insulation on all cables and on the appliance is safe before connecting it to the power supply.

✓ Ensure that cables are always protected against short circuit and overload.

× **DO NOT** use worn or damaged cables, plugs or connectors. Immediately have any faulty item replaced by a qualified electrician.

© Jack Sealey Limited

1.3. BATTERY SAFETY PRECAUTIONS

- ❑ **WARNING!** Batteries contains Lithium-ion which is dangerous. Handle with care to avoid damage, fire, corrosion or personal injury.
- ✓ Charge battery prior to its first use. The battery will have been shipped in a low charge state. To reduce the risk of burns or fire:
- × **DO NOT** attempt to open, disassemble, modify or service the battery pack.
- × **DO NOT** crush, puncture, short external contacts or dispose of in fire or water.
- × **DO NOT** expose to temperatures above 40°C (104°F).
- ✓ Only for use with SV108 series batteries.
- ❑ **WARNING!** Dispose of spent batteries correctly as they contain Lithium-ion. **DANGER! DO NOT** attempt to disassemble the battery. For safety and environmental reasons **DO NOT** discard in domestic waste or by burning. ONLY discard or recycle according to local authority regulations.
- ❑ **WARNING! DO NOT** allow a leaking battery to contact your person.

Children from age 8 years and above, persons with reduced physical, sensory, or mental capabilities those with lack of experience and knowledge can use the appliance, if they have been given supervision or instruction concerning use of the appliance in a safe way to understand the hazards involved.

Children shall **NOT** play with the appliance

2. INTRODUCTION

For recharging SV10.8 series lithium-ion battery packs. Compatible battery Model No's CP108VBP and CP108VBP4. European Plug.

3. SPECIFICATION

Model No.: CP108VMCEU
Output.....10.8V DC 2.4A
Power Supply Cable Length:..... 1.5m
Supply.....230V~ 50/2.4A

4. OPERATION

NOTE: When new, the batteries will have been shipped in a low charge state. Fully charge the batteries before using your tool.

4.1. To remove the battery from the equipment, depress the spring loaded button on the battery pack. Remove the battery pack by sliding out. **DO NOT** touch the metal battery terminals.

4.2. The battery is designed to fit into the charger one way only. Insert the battery fully and firmly to seat the battery into the charging base.

4.3. Take the base charger and plug it into the mains, switch on the power and the LED on the charger will illuminate.

4.4. When the battery is on charge the red LED on the charger will illuminate.

4.5. When the green LED on the Charger illuminates permanently the battery is fully charged.

4.6. Remove the battery from the charger. Switch off and remove the plug from the mains.

ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

REGISTER YOUR PURCHASE HERE

WEEE REGULATIONS

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.
Important: No Liability is accepted for incorrect use of this product.
Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR
01284 757500 **sales@sealey.co.uk** **www.sealey.co.uk**

© Jack Sealey Limited