
Parts Information:

Cordless Reciprocating Saw 10.8V SV10.8 Series - Body Only

Model No: CP108VRSBO



Item	Part No.	Description	Qty
1A	CP108VRSBO.01A	Blade Bracket Assembly	1
2	CP108VRSBO.02	Quick Release Chuck Assembly	1
3	CP108VRSBO.03	Retaining Pin	1
4	CP108VRSBO.04	Torsion Spring	1
5	CP108VRSBO.05	Lock Button	1
6	CP108VRSBO.06	Motor Assembly	1
7	CP108VRSBO.07	Holder, Left Side	1
8	CP108VRSBO.08	Guide Rail	1
9	CP108VRSBO.09	Holder, Right Side	1
10	CP108VRSBO.10	Housing	1

Item	Part No.	Description	Qty
11	CP108VRSBO.11	Clip	2
12	CP108VRSBO.12	Self-Lock Button Spring	1
13	CP108VRSBO.13	Self-Lock Button	1
14	CP108VRSBO.14	Switch	1
15	CP108VRSBO.15	Battery Connection	1
17	CP108VRSBO.17	Battery Indicator	1
18	CP108VRSBO.18	Battery Indicator Cover	1
23	CP108VRSBO.23	Housing Screw	10
24	CP108VRSBO.24	Inductance	2

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR

01284 757500 | sales@sealey.co.uk | www.sealey.co.uk