
SEALEY

Parts Information:
Cordless Pressure Washer 20V - Body Only
Model No: CP20VPW



Item	Part No.	Description
1	CP20VPW-01	Lance Assembly
2	CP20VPW-02	Outlet Joint
3	CP20VPW-03	Front Support Cover (Right Side)
4	CP20VPW-04	Front Support Cover (Left Side)
5	CP20VPW-05	Self-Tapping Screw ST3x13
6	CP20VPW-06	Motor Assembly
7	CP20VPW-07	Self-Tapping Screw ST4x12
8	CP20VPW-08	Switch Trigger
9	CP20VPW-09	Intake Valve Assembly

Item	Part No.	Description
10	CP20VPW-10	Switch Locking Knob
11	CP20VPW-11	Switch Spring
12	CP20VPW-12	Gun Handle (Right Side)
13	CP20VPW-13	Protective Plate
14	CP20VPW-14	Self-Tapping Screw ST3x13
15	CP20VPW-15	Gun Handle (Left Side)
16	CP20VPW-16	Soap Bottle
17	CP20VPW-17	Canvas Bag
18	CP20VPW-18	Water Intake Hose 6m

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.
IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person
WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR
01284 757500 | 01284 703534 | sales@sealey.co.uk | www.sealey.co.uk