
Parts Information:
Reciprocating Saw 20V - Body Only
Model No: CP20VRS



Item	Part No.	Description
1	CP20VRS.01	Casing Complete
2	CP20VRS.02	Shock Absorber
3	CP20VRS.03	Gearbox
4	CP20VRS.04	Switch Assembly, Push Button 20A 7.2-24V
7	CP20VRS.07	Switch Lock Button
8	CP20VRS.08	Switch Lock Button Spring
10	CP20VRS.10	Tapping Screw
--	CP20VRS.11	Wood Cutting Blade (Not Shown)

Item	Part No.	Description
--	CP20VRS.12	Metal Cutting Blade (Not Shown)
--	CP20VBP	Power Tool Battery 20V 3Ah Li-Ion (See Catalogue)
--	CP20VBP2	Power Tool Battery 20V 2Ah Li-Ion (See Catalogue)
--	CP20VBP4	Power Tool Battery 20V 4Ah Li-Ion (See Catalogue)
--	CP20VMC	Battery Charger 20V Li-ion (See Catalogue)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.
IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person
WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR
01284 757500 | sales@sealey.co.uk | www.sealey.co.uk