CHAINSAW TEETH SHARPENER

MODEL NO: **CS01S**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.


Refer to instruction manual


Wear eye protection


Wear protective gloves

1. SAFETY

- ✓ Maintain the saw blade sharpener in good condition (use an authorised service agent).
- ✓ Replace or repair damaged parts. Use recommended parts only. Unauthorised parts may be dangerous and will invalidate the warranty.
- ✓ Keep the sharpener clean for best and safest performance and check moving parts alignment regularly.
- ✓ **WARNING!** Before each use check that the cutting whetstone is secure and that it is not worn or damaged. **NOTE:** Only competent persons should change whetstones.
- ✓ Ensure that replacement whetstones are not damaged in any way - cracks or deformations etc. Also check the mounting flanges to check that they are not deformed, burred or chipped. **DO NOT** tamper with a whetstone in order to adapt it to a different size holder.
- ❑ **WARNING!** Never operate the sharpener without the grinding wheel cover in place.
- ❑ **WARNING!** This machine is designed to sharpen chain saw chains. **DO NOT** attempt to sharpen any other tools and **DO NOT** attempt to grind any other objects.
- ❑ **WARNING!** Wear approved safety eye protection, ear defenders and gloves.
- ✓ Remove ill fitting clothing. Remove ties, watches, rings and other loose jewellery and contain long hair.
- ✓ Maintain correct balance and footing. Ensure the floor is not slippery and wear non-slip shoes.
- ✓ Keep children and unauthorised persons away from the work area.
- × **DO NOT** allow untrained persons to operate the saw blade sharpener.
- × **DO NOT** get the sharpener wet, or use in damp or wet locations or areas where there is condensation.
- × **WARNING! DO NOT** use the saw blade sharpener where there are flammable liquids, solids or gases such as paint solvents and including waste wiping rags etc.

2. INTRODUCTION

Lightweight and portable for use anywhere on 14” to 20” chainsaws. Single sharpening stone in unit. (Supplied with 2 x spare whetstones.) A few seconds and the teeth will be back to full sharpness. Just a few drops of oil and it is ready to use.

3. SPECIFICATION

Model No:.....CS01S
Chain Sizes:.....14, 16, 18, 20”
Consumables:..... Sharpening Whetstone CS01SW

4. OPERATION






fig.1

Open chainsaw sharpener fig.1.


fig.2

Attach on two holes of the sharpener fig.2.


© Jack Sealey Limited




Close sharpener and push lock fig.3.



Run chainsaw whilst gently squeezing the chainsaw sharpener down until the teeth touch the whetstone for 3 to 5 seconds.




For use with single pin chainsaw



Slide the smaller pin towards the fixed pin and lift out, fig.6.

5. MAINTENANCE

Remove whetstone as per fig.7 and reverse the operation to refit new whetstone.



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.
Important: No Liability is accepted for incorrect use of this product.
Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

REGISTER YOUR PURCHASE HERE

Jack Sealey (EU) Ltd t/a Sealey Group Farney Street, Carrickmacross, Co. Monaghan, A81 PK68 Ireland
Jack Sealey Ltd t/a Sealey Group Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk, IP32 7AR UK
Tel: 01284 757500 ▪ **Email:** sales@sealey.co.uk ▪ **Web:** www.sealey.co.uk

© Jack Sealey Limited