FORK MOUNTED SKIPS

Base Emptying Stillage - Fully Automatic



The fully automatic base emptying stillage is emptied entirely from the forklift cab. There are no cords, wires or pulleys and nobody needs to climb up or stand near the raised load: the operator lifts it over the receptacle, opens the base and lowers it back down to re-lock.

- ✓ Emptied entirely from the cab
- ✓ No cords, wires or pulleys
- ✓ Base re-locks automatically when lowered

PART NO. WOS-FA-1017

PRICE ON APPLICATION Contact us for a quote

KEY FEATURES

- 0.5 to 2.0 m³
- 2 mm steel sides and 3 mm base
- Stackable on pallet feet, castors on larger sizes
- Safety securing chain
- Choice of colours for waste segregation

SPECIFICATIONS

Part no.	Option	Volume (m^3)	Overall Length (mm)	Overall Width (mm)	Overall Height (mm)
WOS-FA-1017-01	0.5 m³	0.5	1020	870	920
WOS-FA-1017-02	0.7 m³	0.7	1020	970	1080
WOS-FA-1017-03	1.0 m³	1.0	1320	1050	1080
WOS-FA-1017-04	1.5 m³, on castors	1.5	1690	1050	1080
WOS-FA-1017-05	2.0 m³, on castors	2.0	2000	1050	1080

Dimensions in mm, weights in kg. For a quote or advice on the right option for your truck, contact WOLFF Onsite at hello@wolffonsite.co.uk or call 01709 437141.