JIBS

Forklift Cross Beam Jib

The cross beam jib does two jobs: use it as a conventional forklift jib or turn it across the truck as a 2,000 mm spreader beam. It is ideal for long or wide loads such as steel lengths, pipes and panels.

- ✓ Jib or spreader beam in one
- ✓ 2,000 mm beam
- ✓ 500 kg as a jib, 2,000 kg as a spreader beam

PART NO. WOS-FA-1100



KEY FEATURES

- Two hooks and shackles
- Large fork pockets and safety chain

SPECIFICATIONS

Specification	Value
Capacity In Jib Position (kg / load centre mm)	500 / 2000
Capacity In Beam Position (kg / load centre mm)	2000 / 500

Dimensions in mm, weights in kg. For a quote or advice on the right option for your truck, contact WOLFF Onsite at hello@wolffonsite.co.uk or call 01709 437141.